

Epson Stylus Pro 4400/4800/4880 Error Codes

- **Maintenance Request Codes:**
 - 0002 - CR Motor near end of life - Replace carriage return motor ASAP
 - 0006 - Battery shut off - Replace RTC back-up battery
 - 0040 - Cleaning unit near end of life - Replace cleaning unit ASAP
 - 0080 - Date not set - Set the date through the printer control panel
 - 0088 - RTC backup battery not installed - Install RTCbackup battery
 - 0100 - RTC backup battery pressure is temporally low - wait for a while
 - 0200 - The number of ASF paper feeding has reached predetermined value
-
- **Service Call Codes**
 - 00000101 - CR Motor reached end of life - Replace carriage return motor
 - 00010000 - PF encoder check error
 - 00010001 - PF motor is out of step
 - 00010002 - PF motor overcurrent has occurred - Replace PF motor
 - 00010003 - PF motor out of position time-out error
 - 00010004 - CR encoder check error - ensure encoder strip is clean & dust free
 - 00010005 - CR motor out of step - [click here for more info](#)
 - 00010006 - CR motor over current
 - 00010007 - CR motor out of position time-out error - Replace the board assembly, main
 - 00010008 - Servo interrupt watchdog time-out error - Replace the board assembly, main
 - 0001000A - Carriage home position detection error
 - 0001000C - PG home position detection error
 - 0001000F - CR motor PWM output faulty
 - 00010010 - PF motor PWM output faulty
 - 00010012 - CR overload (high sensitivity) error
 - 00010013 - PF overload (high sensitivity) error
 - 0001001B - Head Driver (TG) temperature error
 - 0001001D - CR servo parameter error
 - 0001001E - PF servo parameter error
 - 00010020 - CSIC reading/writing error
 - 00010022 - Ink type error (setting on printer body side)
 - 00010023 - RTC analyzing error
 - 00010025 - SCIS ROM communication error
 - 00010026 - RTC communication error - [click here for more info](#)
 - 00010028 - Head error - replace print head
 - 00010029 - Unidentified NMI

- 0001002A - CR ASIC ECU error - Reinstall/update firmware
- 0001002B - PF ASIC ECU error
- 0001002D - Cleaning unit has reached end of life - replace cleaning unit
- 0001002F - 360 DPI writing time-out error
- 00010030 - Multi sensor error
- 00010031 - ASF phase detection error
- 00010032 - ASF drive switch error
- 00010033 - Eject phase detection error
- 00010034 - Eject movement error
- 00010035 - Pump phase detection error
- 00010036 - Type-B board installation error
- 00010037 - Head thermistor error - Replace print head
- 00010038 - Transistor thermistor error - Replace board assembly, main
- 00010039 - PG adjustment value incorrect overwrite error
- 0001003A - PG adjustment value outside range error
- 0001003B - Cutter installation error 1
- 0001003C - Cutter installation error 2
- 0001003D - Cutter installation error 3
- 00020000 - NVRAM error - Replace board assembly, main
- 00020002 - SDRAM error - Replace board assembly, main
- 00020003 - Boot program SUM error - [click here for more info](#)
- 00020009 - Flash memory SUM error
- 0002000A - Program load error
- 0002000B - The internal memory is insufficient
- 100000E0 - CPU address error (load)
- 10000100 - CPU address error (store)
- 10000180 - CPU reserved command code exception error
- 100001A0 - CPU slot undefined command exception error
- 100001C0 - The AC power is shut off
- 100005C0 - CPU DMA address error
- 10000xxx - CPU error
- 0003xxxx - Debug orode
- 0Dxxxxxx - An error code for debugging
- 0Exxxxxx - A time-lag of the RTC timer