

Installation de votre imprimante dans le rip...




neoStampa 8

- File
- Edit
- View
- Tools
- Help

- New Ctrl+N
- Open... Ctrl+O
- Configure Printer...
- Exit

Vertical toolbar with icons for: Save, Undo, Redo, Copy, Paste, Print, Erase, Fill, Pattern, Gradient, Stamp, Stamp with pattern, Stamp with gradient, Stamp with pattern and gradient, Stamp with pattern and gradient and fill, Stamp with pattern and gradient and fill and pattern.

Control center



Apply, Undo, Redo, RIP...



Cliquez sur "Add" pour ajouter votre imprimante. Le rip génère alors une liste d'imprimantes...

Printer configuration Close

List of installed printers

Name	Connection	St...	

Add... Remove


Device configuration:

Connection:  Test...

Options...

Advanced... Use this button to setup several options for this device

Control center

Apply ↶ 📄🖨️ RIP...



Printer configuration

List of installed printers

Name	Connection	St...

Close

Scanning drivers... [54%]

KonicaMinolta.dll

Progress bar (54% complete)

Cancel

Device: [Empty field]

Connection: [Dropdown menu]

Test...

Options...

Advanced... Use this button to setup several options for this device




Choisissez votre imprimante dans la liste.


Add drivers

These are all available drivers. Select the desired ones and press 'Install':

Brand:	Model:
Arioli	Epson SureColor SC-F6000
Blue Plan CS	Epson SureColor SC-F7000
Canon	Epson SureColor SC-S30600
DGI	Epson SureColor SC-S50600 (4-color)
DuPont	Epson SureColor SC-S50600 (5-color)
Durst	Epson SureColor SC-S70600 (10-color)
EFI VUTEk	Epson SureColor SC-S70600 (8-color)
ESATEX	Epson SureColor SC-T3000
Encad	Epson SureColor SC-T3200
Epson	Epson SureColor SC-T5000
FTex	Epson SureColor SC-T5200
Gandinnovations	Epson SureColor SC-T5200D
Graphtec	Epson SureColor SC-T7000
Hewlett Packard	Epson SureColor SC-T7200

Install Cancel






**Add drivers** [Close]

These are all available drivers. Select the desired ones and press 'Install':

Brand:	Model:
Arioli	Epson SureColor SC-F6000
Blue Plan CS	Epson SureColor SC-F7000
Canon	Epson SureColor SC-S30600
DGI	Epson SureColor SC-S50600 (4-color)
DuPont	Epson SureColor SC-S50600 (5-color)
Durst	Epson SureColor SC-S70600 (10-color)
EFI VUTEk	Epson SureColor SC-S70600 (8-color)
ESATEX	Epson SureColor SC-T3000
Encad	Epson SureColor SC-T3200
Epson	Epson SureColor SC-T5000
FTex	Epson SureColor SC-T5200
Gandinnovations	Epson SureColor SC-T5200D
Graphtec	Epson SureColor SC-T7000
Hewlett Packard	Epson SureColor SC-T7200

[Install] [Cancel]



Vous pouvez modifier ici le nom affiché de votre imprimante, ou garder celui par défaut.

Printer configurat

List of installed pri

Name

Close

Printer's name

Write the printer's name to use in future references:

Name:

We recommend you to use the default name or one that allows you to easily identify the printer and configuration.

Ok Cancel

Device confi

Connec

Options...

Advanced... Use this button to setup several options for this device



Vous devez choisir ici le port sur lequel est branchée votre imprimante : soit sur le port usb, soit sur le port réseau.

Printer configuration

List of installed printers

Name	Connection	St...
Epson SureColor SC-T3200	TCP/IP:192.168....	Pr...

Close

Add... Remove



Device configuration:

Connection: TCP/IP: (TCP/IP Network)

- LPT1: (Parallel Port)
- LPT2: (Parallel Port)
- LPT3: (Parallel Port)
- USB: (Universal Serial Bus)
- TCP/IP: (TCP/IP Network)
- SPOOLER: (Windows Printer Driver)
- FILE: (File)
- NULL:

Test... Options...

Advanced options for this







Si l'imprimante est sur le port réseau, choisissez "TCPIP".  
Pour modifier l'adresse réseau de l'imprimante, cliquez sur "Option".

Printer configuration

List of installed printers

Name	Connection	St...	
Epson SureColor SC-T3200	TCP/IP:192.168....	Pr...	


Close


Add... Remove

Device configuration:

Connection: TCP/IP: (TCP/IP Network) Test...  
192.168.0.1:9100 Options...

Advanced... Use this button to setup several options for this device





Printer configuration

List of installed printers

Name	Connection	St
Epson Sur		

Close

Device co

Con

Advanced... Use this button to setup several options for this device

TCP/IP Port Setup

Host Specification:

By Host Name

Host Name:

By IP Address


IP Address:

Port Number:

Block size:  KB

Ok

Cancel



Printer configuration [Close]

List of installed printers

Name	Connection	St...	
Epson SureColor SC-T3200	USB:	Pr...	

Add... Remove

Device configuration:

Connection: **USB: (Universal Serial Bus)**

- LPT1: (Parallel Port)
- LPT2: (Parallel Port)
- LPT3: (Parallel Port)
- USB: (Universal Serial Bus)**
- TCPIP: (TCP/IP Network)
- SPOOLER: (Windows Printer Driver)
- FILE: (File)
- NULL:

Test... Options...

Si l'imprimante est sur le port USB, choisissez "USB".



Printer configuration

List of installed printers

Name	Connection	St...	
Epson SureColor SC-T3200	USB:	Pr...	

Close


Add... Remove


Device configuration:

Connection: USB: (Universal Serial Bus) Test... Options...

Advanced... Use this button to setup several options for this device

Cliquez sur "Option" pour détecter sur lequel des ports USB est connectée votre imprimante.





Printer configuration

List of installed printers

Name	Connection	St...	
Epson SureColor SC-T3200	USB:	Pr...	

USB connection settings

USB device identification

Vendor ID:  Block size:  KB

Device ID:

Currently detected USB devices:


Vendor ID	Product ID	Instance	Path
Logitech, Inc. (1133)	? (2085)	14DBC220	\\?\USB#VID_046D&P...
Logitech, Inc. (1133)	? (50475)	5&3478afd2&0&2	\\?\USB#VID_046D&P...
Canon, Inc. (1193)	? (4258)	B4F4BC	\\?\USB#VID_04A9&P...
Canon, Inc. (1193)	? (8741)	6&1afef69a&0&4	\\?\USB#VID_04A9&P...
Ricoh Co., Ltd (1482)	? (6160)	5&a82b49f&0&4	\\?\USB#VID_05CA&P...

**Important : Les imprimantes EPSON apparaissent sous le nom SEIKO.**

Cliquez sur "Detect" pour que le rip scrute les ports USB. Cliquez sur votre imprimante dans la liste et validez en appuyant sur "OK".






Fermez cette fenêtre en cliquant sur "Close".



Printer configuration 


List of installed printers

Name	Connection	Status
Epson SureColor SC-T3200	TCP/IP:192.168....	Predetermined

Device configuration:

Connection:    
 

 Use this button to setup several options for this device

